

SURE-LOCK WB

HIGH PERFORMANCE JOINT STABILIZING SEALER

SURE-LOCK WB may be applied to the surface of the paver with a roller or spray equipment. In either case, it is best to use a squeegee to move most of the material from the surface of the paver into the joint. The effective application rate will vary depending on the width of the joints and the looseness of the sand. For estimating purposes use 100 square feet per gallon as a guideline. To keep the system in good repair, re-sanding and a fresh treatment of SURE-LOCK WB should be considered every other year.



SURE-LOCK WB's water-based formula complies with all federal and state EPA standards and is easy to use. SURE-LOCK WB generally dries in 2 hours and clean-up is with soap and water.

Applying SURE-LOCK WB is an easy and effective way to insure the integrity and beauty of a paver system long after the project is completed.



HIGHLIGHTS OF SURE-LOCK WB

- Prevents water from washing sand from the joints
- Forms a tough non-yellowing film on the paver surface to protect it from the elements
- Enhances the color and beauty of any masonry unit
- Prevents the growth of weeds and grasses from growing in the joints
- Helps stabilize the paver system
- Water-based product for easy use and clean-up



SURE-LOCK WB - The Easy Choice

